

## *How to Apply Bumper and Purch*

1. Find the center halfway posteriorly from one hinge to the other, and apply glue to spot.
2. Cut small piece of plastic (the same material as used on A.F.O.)
3. Heat large and small plastic pieces.
4. When plastic is up to temperature, place on glue spot with two thirds on proximal side.
5. When plastic is cool, remove A.F.O. from cast and cut in two.
6. For **polyurethane cord** type bumper (**B-350, B-400**), use the #36 hole as a pilot, use a letter D drill for a 1/4" and a #13 for a 3/16", then press to fit.
7. For **molded urethane bumper (B-1000, B-2000)**, use the drill included in the kit to make the proper size hole in the A.F.O. posting. Then press to fit.